

FAQ - HOW TO USE THE FULL ALPHA BANDS (A-Z)

A typical alpha or numeric band in a hand labeller has two sides to it - The reading face and the print face.

Due to the limited space available on a print band with the full alphabet, the letters must run all the way around the band. This means that the reading face will not reflect what is to be printed, as it is the opposite side of the band.

EG, if you were printing the word "SHOP" the read letters facing for view would be "FUBC", the opposite of these would read your required word "SHOP"

Reference the below table -

READ	PRINT	READ	PRINT
A	N	N	A
B	O	O	B
C	P	P	C
D	Q	Q	D
E	R	R	E
F	S	S	F
G	T	T	G
H	U	U	H
I	V	V	I
J	W	W	J
K	X	X	K
L	Y	Y	L
M	Z	Z	M

A small "Print Guide" label is also attached to the side of your gun to assist with printing the correct letter(s), when you wish to change formatting.

Please note that sometimes the letter on the reading face will look like it's upside down or back to front. This is to be expected, however it will not affect the orientation of the letter(s) to be printed.

For more helpful Tips & Support, as well as other products please visit our website -

www.saito.co.nz